

# Reprocessing Instruction

Air Scaler

#### Preparation 1



2 Cleaning, Disinfection and Drying

#### <For S970 Series>

Manual





After cleaning remove any remaining moisture using a dry cloth or compressed air ensuring it is dry internally and externally.

· Cover the product with a cloth when drying with compressed air to prevent water aerosol from being produced. • Use a nationally approved disinfectant with proven bactericidal, fungicidal, and virucidal properties.

# <For AS2000 / S950 / S900 Series>



## 3 Lubrication

### <For S970 Series> Manual



⚠ • Do not use spray lubricant for AS2000/S900/S950 Series. The air scaler could come off under the pressure of the spray.

# 4 Packaging, Sterilizing and Drying



Туре	Class N	Class B
Temperature	132°C	134°C
FullCycleTime	≥15min	3-18min
Drying Time	≥30min	≥30min

Perform steam sterilization using the conditions above.

Use a steam sterilizer to perform sterilization.



Use a sterilization pouch that conforms to ISO 11607-1. Seal the pouch. Maximum temperature for NSK instruments is 135°C.

#### 5 Storage



NAKANISHI INC. **ml** 700 Shimohinata, Kanuma, Tochigi 322-8666, Japan

NSK Europe GmbH ECREP Elly-Beinhorn-Strasse 8, 65760 Eschborn, Germany

